

Product No. WH0106

Not suitable for  
children under  
36 months due  
to small parts.

# Wishing Watch

Magic Happens at **11:11!**


11:11. A moment of magic where every-  
thing lines up perfectly. Some believe it's  
a sign of good luck. We believe it's the  
ideal time to make a wish.

**May all your wishes  
come true!!**

**YOUR WISHING WATCH ALARM HAS BEEN PRESET TO 11:11AM.**

## TO SET TIME:

- 1) Press 'B' 6 times to display the HOUR.
- 2) Change the HOUR by pressing 'A' until the desired HOUR is selected.
- 3) Press the 'B' 1 time to display the MINUTES.
- 4) Change the MINUTES by pressing 'A' until the desired MINUTE is selected.
- 5) Press 'B' 1 time and then press 'A' 1 time.



## TO RESET THE ALARM:

- 1) Press 'B' 1 time showing flashing numbers.
- 2) Be sure you see 'bell' and 'sound' icons. (If not, press 'A' 2 times until they appear together)
- 3) Press 'B' 1 more time to display the HOUR.
- 4) Change the HOUR by pressing 'A' until the desired HOUR is selected.
- 5) Press 'B' 1 time to display the MINUTES.
- 6) Change the MINUTES by pressing 'A' until the desired MINUTE is selected.
- 7) Press 'B' 1 time. The watch will now display the time.

[www.wishingwatch.com](http://www.wishingwatch.com)

©2011 Wishing Watch, La Canada, CA 91011

Questions or comments, please visit us on the web at [www.wishingwatch.com](http://www.wishingwatch.com)

Made in China



8 5 6 9 6 2 0 0 3 0 0 5